



CONNECTING THE WHOLE SYSTEM FOR LARGE FORMAT

NOTE Only one audio input can be used at once.
Audio Inputs: DVD, AUX 1, AUX 2, AUX 3, Optical Digital, and Coaxial Digital

