


## The Smart Auto Input Switching (SAIS) function

"Smart" Auto Input Switching Function is unlike regular Auto Selection Function which first signal received from terminal will be switched to that terminal regardless of input priority. However, "Smart" Auto Switching Function reserves the first priority for main input VOD, then BGM not Manual input terminal.



### DX-288 Source Input

→ DVD	CDG	VOD
Manual	BGM	MAIN

### DX-5000 Source Input

CDG	→ DVD	VOD
Manual	BGM	MAIN

### DX-3000 Source Input

→ AUX	CDG	DVD
Manual	BGM	MAIN

### DX-222 Source Input

→ AUX	CDG	DVD
Manual	BGM	MAIN

When three terminals (i.e. Main, BGM and Manual) are all operating (i.e. music source is playing) at the same time, the Smart Auto Input Switching would give the Main input terminal the first priority to operate. Even though other source is manually/remote selected while Main input terminal has signal, it will automatically switch back to the Main input selection because SAIS is active.

If you want to select BGM or Manual inputs, you MUST stop the Main input source from playing. Then you can select manually between BGM and Manual selections.

This SAIS feature is special designed by Better Music Builder for commercial KTV use.

